

Pesukoneen täyttöluukun avaaminen ongelmatilanteissa

Ohjeet täyttöluukun avaamiseen ongelmatilanteissa, esimerkiksi sähkökatkon sattuessa:

1. Katkaise virta turvakytkimestä ja varmista, ettei rummussa ole vettä ja kone on täysin pysähtynyt. Palovammavaaran vuoksi ethän avaa täyttöluukkuja, jos näyttö ilmoittaa koneen olevan liian kuuma tai koneen osat tuntuvat kuumilta.
3. Työnnä luukunkehystä rumpuallasyksikköä kevyesti taaksepäin.
4. Työnnä sormesi etupaneelin reunan taakse täyttöluukun kahvan kohdalta ja paina etupellin takana olevaa luukun lukkolaitteen avauspainiketta.
5. Käännä täyttöluukun kahvaa myötäpäivään ja vedä luukku kevyesti auki.

Opening laundry filling hatch in case of a problem

Opening the filling hatch in case of a problem, e.g. in the event of a power outage:

1. Switch off the power at the safety switch, and make sure there is no water in the drum and the machine has stopped completely. In addition, to avoid the risk of burn injuries, do not open the filling hood if the message "too hot" is displayed on the screen or if parts of the machine appear to be hot.
2. Gently push the drum unit backwards from the hatch frame.
3. Insert your finger behind the edge of the front panel at the filler door handle and press. Press the button on the front panel behind the front panel to open the hatch lock device.
4. Turn the filler door handle clockwise and gently pull the door open.

