

SLF400 – FOLDING MANUAL

1.



2.




3.



4.




5.




SLF400 – UNFOLDING MANUAL

1.




2.



3.



4.



5.

